

Experiment Title: 5

Student Name: Pratibha

UID: 18BCS6093

Branch: AIML-1

Section/Group: B

Semester: 5

Date of Performance:

Subject Name: DIP LAB

Subject Code: CSF-336

1. Aim/Overview of the practical:

Write the python program which help us to understand

- a) The Color spacing and data analytics of images without using opencv .
- b) Image operations and analysis using opencv

2. The task to be done:

- a) The Color spacing and data analytics of images without using opencv .
- b) Image operations and analysis using opencv

3. Required libraries or software

```
import numpy as np
import imageio
import matplotlib.pyplot as plt
import cv2 as cv
```

4. Algorithm/Flowchart :

5. Theme/Interests definition(For creative domains):

6. Steps for experiment/practical:

```
# ## Reading and Displaying of image with ImageIO
# In[1]:
```

```

# Importing required modules
import imageio
import numpy as np
import matplotlib.pyplot as plt

# The output of plotting commands is displayed inline within frontends.
get_ipython().run_line_magic('matplotlib', 'inline')
img = imageio.imread('aa.jpg')
plt.figure(figsize = (9,6))
plt.imshow(img)

### Printing the description of image (height,width,rgb value etc)
# In[2]:
print('Type of the image : ' , type(img))
# The shape of the ndarray shows that it is a three-layered matrix
print('Shape of the image : {}'.format(img.shape))
print('Image Hight {}'.format(img.shape[0]))
print('Image Width {}'.format(img.shape[1]))
print('Dimension of Image {}'.format(img.ndim))
# ndim() function return the number of dimensions of an array
print('Image size {}'.format(img.size))
print('Maximum RGB value in this image {}'.format(img.max()))
print('Minimum RGB value in this image {}'.format(img.min()))
# A specific pixel located at Row : 110 ; Column : 60
# Each channel's value of it, gradually R , G , B
print('Value of only R channel {}'.format(img[ 110, 60, 0]))
print('Value of only G channel {}'.format(img[ 110, 60, 1]))
print('Value of only B channel {}'.format(img[ 110, 60, 2]))

### To see the specific channel of image

# In[3]:
# To see the R channel

```

```
plt.title('R channel')
plt.ylabel('Height {}'.format(img.shape[0]))
plt.xlabel('Width {}'.format(img.shape[1]))
plt.imshow(img[ : , : , 0])
plt.show()
```

```
# In[4]:
# To see the G channel
plt.title('G channel')
plt.ylabel('Height {}'.format(img.shape[0]))
plt.xlabel('Width {}'.format(img.shape[1]))
plt.imshow(img[ : , : , 1])
plt.show()
```

```
# In[5]:
# To see the B channel
plt.title('B channel')
plt.ylabel('Height {}'.format(img.shape[0]))
plt.xlabel('Width {}'.format(img.shape[1]))
plt.imshow(img[ : , : , 2])
plt.show()
```

```
### To see the intensity of channel in particular pixel range
# As an example,
# R channel: Row – 100 to 110
# G channel: Row – 200 to 210
# B channel: Row – 300 to 310
```

```
# In[6]:
# full intensity to those pixel's R channel
img[50:100 , : , 0] = 255
plt.figure( figsize = (9,6))
plt.imshow(img)
```

```
plt.show()
```

```
# In[7]:
```

```
# full intensity to those pixel's G channel
```

```
img[150:200 , : , 1] = 255
```

```
plt.figure( figsize = (10,6))
```

```
plt.imshow(img)
```

```
plt.show()
```

```
# In[8]:
```

```
# full intensity to those pixel's B channel
```

```
img[250:300 , : , 2] = 255
```

```
plt.figure( figsize = (9,6))
```

```
plt.imshow(img)
```

```
plt.show()
```

```
# In[9]:
```

```
img[ 50:250 , 300:400 , [0,1,2] ] = 100
```

```
plt.figure( figsize = (5,5))
```

```
plt.imshow(img)
```

```
plt.show()
```

```
# In[10]:
```

```
import numpy as np
```

```
pic = imageio.imread('aa.jpg')
```

```
fig, ax = plt.subplots(nrows = 1, ncols=3, figsize=(15,5))
```

```
for c, ax in zip(range(3), ax):
```

```
    # create zero matrix
```

```
    split_img = np.zeros(pic.shape, dtype="uint8")
```

```
# 'dtype' by default: 'numpy.float64'
# assing each channel
split_img[:, :, c] = pic[:, :, c]
# display each channel
ax.imshow(split_img)
```

```
# In[11]:
```

```
pic = imageio.imread('aa.jpg')
plt.figure(figsize=(9,5))
plt.imshow(pic)
plt.show()
```

```
# In[12]:
```

```
low_pixel = pic < 20
# to ensure of it let's check if all values in low_pixel are True or not
if low_pixel.any() == True:
    print(low_pixel.shape)
# In[13]:
print(pic.shape)
print(low_pixel.shape)
```

```
# ## Convert Images into different image form
```

```
# In[ ]:
```

```
import cv2
import numpy as np
img = imageio.imread('aa.jpg')
retval, threshold = cv2.threshold(img, 12, 255, cv2.THRESH_BINARY)
cv2.imshow('original',img)
```

```

cv2.imshow('threshold',threshold)
cv2.waitKey(0)
cv2.destroyAllWindows()

# In[ ]:
import cv2
import numpy as np
grayscaled = cv2.cvtColor(img,cv2.COLOR_BGR2GRAY)
retval, threshold = cv2.threshold(grayscaled, 10, 255, cv2.THRESH_BINARY)
cv2.imshow('original',img)
cv2.imshow('threshold',threshold)
cv2.waitKey(0)
cv2.destroyAllWindows()

```

```

# In[ ]:
import cv2
import numpy as np
img = cv2.imread('aa.jpg')
grayscaled = cv2.cvtColor(img,cv2.COLOR_BGR2GRAY)
gaus = cv2.adaptiveThreshold(grayscaled, 255, cv2.ADAPTIVE_THRESH_GAUSSIAN_C,
cv2.THRESH_BINARY, 115, 1)
cv2.imshow('original',img)
cv2.imshow('threshold',threshold)
cv2.imshow('Adaptive threshold',gaus)
#cv2.imshow('threshold2',threshold2)
cv2.waitKey(0)
cv2.destroyAllWindows()

```

```

retval2, threshold2
cv2.threshold(grayscaled,125,255,cv2.THRESH_BINARY+cv2.THRESH_OTSU)
cv2.imshow('original',img)
cv2.imshow('Otsu threshold',threshold2)
cv2.waitKey(0)
cv2.destroyAllWindows()

```

Thank You for visiting my worksheet



7. Observations/Discussions(For applied/experimental sciences/materials based labs):


8. Percentage error (if any or applicable):


9. The command that we have learned today in the program :





10. Result/Output/Writing Summary of the concept behind the experiment:











11. Graphs (If Any): Image /Soft copy of graph paper to be attached here